


**Important!**  
Do not change the speaker  
and power connection!

To the starting input can be  
attaching only 0-5 volts.  
Or a "contact," between to the input and GND.

MP3 modul:

\ 0001.mp3



+ Speaker 8 - 16 ohm  
- at least 3 watt

**Voice volume setting:**  
+ : Hold down K2, and press the K1 button  
- : Hold down K3, and press the K1 button

**Play mode choice:**  
voice playing to ending/or restart:  
K3 + K1 + K2 pressed for 5 seconds

5 volt supply voltage output.  
If necessary, it can feed for  
example a sensor

Input GND  
+  
Power supply  
DC 9-15V/500mA